


OVERGANGSTABELL

DRIVLINJER


FØR

NÅ

Transmax Z	 TRANSMAX ATF Z
Transmax Dex III Multivehicle	TRANSMAX ATF DX III Multivehicle
ATF Dex II Multivehicle	TRANSMAX ATF DX II Multivehicle
Autran MBX	TRANSMAX ATF DX II Multivehicle
Syntrans Z Long Life 75W-80	TRANSMAX Manual Z Long Life 75W-80
Syntrans Z 75W-80	TRANSMAX Manual Z 75W-80
Syntrans 75W-85	TRANSMAX Manual Long Life 75W-85
Energear SHX 30	TRANSMAX Manual Long Life 75W-85
Syntrans AT 75W-90	TRANSMAX Manual AT 75W-90
Manual EP 80W	TRANSMAX Manual EP 80W

FØR

NÅ

Manual EP 80W-90	 TRANSMAX Manual EP 80W-90
Syntrax Long Life 75W-90	TRANSMAX Axle Long Life 75W-90
Syntrax Long Life 75W-140	TRANSMAX Axle Long Life 75W-140
Syntrax Limited Slip 75W-140	TRANSMAX Limited Slip LL 75W-140
Axle EPX 90	TRANSMAX Axle EPX 85W-90
Energear Hypo 90	TRANSMAX Axle EPX 85W-90
Axle EPX 80W-90	TRANSMAX Axle EPX 80W-90
Energear Hypo 80W-90	TRANSMAX Axle EPX 80W-90
Axle EPX 85W-140	TRANSMAX Axle EPX 85W-140
Energear Hypo 85W-140	TRANSMAX Axle EPX 85W-140
Axle Z Limited Slip 90	TRANSMAX Limited Slip Z 85W-90
Energear SHX-LS 75W-90	TRANSMAX Limited Slip 75W-90
Syntrax Universal Plus 75W-90	TRANSMAX Universal LL 75W-90
Energear SHX-M 75W-90	TRANSMAX Universal LL 75W-90
Syntrax Universal 80W-90	TRANSMAX Universal LL 80W-90
Energear HT 80W-90	TRANSMAX Universal LL 80W-90
Universal 75W-90	TRANSMAX Universal 75W-90
Energear HT 75W-90	TRANSMAX Universal 75W-90
Transmax Offroad 10	TRANSMAX Offroad 10
Transmax Offroad 30	TRANSMAX Offroad 30
Transmax Offroad 50	TRANSMAX Offroad 50

